



Five volts is available on the mini panel by soldering a wire to the indicated hole (above). To avoid potential damage to the mini panel or BD20 use only the 5 volts from the mini panel. There are no specific voltage or current requirements for the transistor as long as it is an NPN transistor. The 1 K resistor can be any wattage, 1/4 Watt is the most common.